


## 1. Remote control

Button 1 = Will hold the gate open.  
Push button 1 again to close the gates.



## 2. Key switch

If the key switch is OFF, the gate will start flashing red. The gate will not open since there is no power to the motor.  
When the key is turned off you are able to push the gate arm to open or close.

ON = Key is vertical.




### 3. Normal opening for entrance gates

When someone walks towards the entrance gates, the radar/radars will be triggered, and the gates will open.

When the gates doesn't get the opening signal from the radars, the gates will stay open for a short pre-configured time.

See below overview for a better understanding of the detection area.

#### Overview of the RADAR



### 4. Contact details

Support – [support@radfordretail.com](mailto:support@radfordretail.com)

Parts – [parts@radfordretail.com](mailto:parts@radfordretail.com)

Service – [peter@tardis.nz](mailto:peter@tardis.nz)